

# EVA Checklist

## STS-121 Flight Supplement

**Mission Operations Directorate  
EVA, Robotics, and Crew Systems  
Operations Division**


**Basic  
January 10, 2005**

**NOTE**

This supplement is to be integrated into the generic edition to provide a complete document for the specific flight. Some pages in the generic edition may be replaced with supplemental pages identified as 'TEMP'. These generic pages, if any, must be retained for use on future flights.

National Aeronautics and  
Space Administration

**Lyndon B. Johnson Space Center**  
Houston, Texas





MISSION OPERATIONS DIRECTORATE

**EVA CHECKLIST  
STS-121 FLIGHT SUPPLEMENT**

BASIC  
January 10, 2005

PREPARED BY:

Karina Shook  
Karina B. Shook  
Book Manager

APPROVED BY:

Mary A. Fitts  
Mary A. Fitts  
Lead, EVA Systems Group

Randall S. McDaniel  
Randall S. McDaniel  
Lead, EVA Task Group

Mary A. Fitts  
Chief, EVA and Crew Systems Operations Branch

This document is under the configuration control of the Crew Procedures Control Board (CPCB). Except for Discrepancy Notices (DN) approved at the flight operations review (FOR), all proposed changes must be submitted via FDF Workflow Crew Procedure Change Request (CR) to DO3/FDF Manager.

Additional distribution of this book, for official use only, may be requested in writing to DO3/FDF Manager. The request must include justification and requester's name, organization, position, and phone number. Contractor requests are made through the NASA or DOD organization supported. Deletions, reduction in quantity, or change of address may be submitted to DO3/FDF Management Office, 281-244-1184.

|                             |
|-----------------------------|
| Incorporates the following: |
|-----------------------------|

|                                   |
|-----------------------------------|
| 482#: None – Establishes baseline |
|-----------------------------------|

AREAS OF TECHNICAL RESPONSIBILITY

|                        |                   |              |
|------------------------|-------------------|--------------|
| Book Manager           | DX32/K. Shook     | 281-483-4474 |
| Alternate Book Manager | DX32/G. Schneider | 281-244-1147 |

**EVA CHECKLIST**  
**STS-121 FLIGHT SUPPLEMENT**  
**LIST OF EFFECTIVE PAGES**

BASIC      01/10/05

|                   |   |         |                  |         |
|-------------------|---|---------|------------------|---------|
| Sign Off .....    | * | 121/BAS | 3-11 .....       | generic |
| FS ii.....        | * | 121/BAS | 3-12 .....       | generic |
| iii.....          | * | generic | TEMP FS 4-1..... | 121/BAS |
| iv .....          | * | generic | TEMP FS 4-2..... | ALL/BAS |
| FS v.....         | * | 121/BAS | 4-3 .....        | generic |
| FS vi.....        | * | 121/BAS | 4-4 .....        | generic |
| FS vii.....       | * | 121/BAS | 4-5 .....        | generic |
| FS viii .....     | * | 121/BAS | 4-6 .....        | generic |
| FS ix.....        |   | 121/BAS | 4-7 .....        | generic |
| FS x.....         |   | 121/BAS | 4-8 .....        | generic |
| FS xi.....        |   | 121/BAS | 4-9 .....        | generic |
| FS xii .....      |   | 121/BAS | 4-10 .....       | generic |
| FS xiii .....     |   | 121/BAS | FS CC 4-11.....  | 121/BAS |
| FS xiv .....      |   | 121/BAS | FS CC 4-12.....  | 121/BAS |
| 1-1 .....         |   | generic | 5-1 .....        | generic |
| 1-2.....          |   | generic | 5-2 .....        | generic |
| 1-3.....          |   | generic | 5-3 .....        | generic |
| 1-4.....          |   | generic | 5-4 .....        | generic |
| 1-5.....          |   | generic | A6-1.....        | generic |
| 1-6.....          |   | generic | CC A6-2.....     | generic |
| 1-7.....          |   | generic | 6-3 .....        | generic |
| 1-8.....          |   | generic | CC 6-4 .....     | generic |
| 1-9.....          |   | generic | FS 7-1 .....     | 121/BAS |
| 1-10.....         |   | generic | FS 7-2 .....     | 121/BAS |
| TEMP FS 2-1 ..... |   | 121/BAS | FS 7-3 .....     | 121/BAS |
| TEMP FS 2-2 ..... |   | ALL/BAS | FS 7-4 .....     | 121/BAS |
| 2-3.....          |   | generic | FS 7-5 .....     | 121/BAS |
| 2-4.....          |   | generic | FS 7-6 .....     | 121/BAS |
| 2-5.....          |   | generic | FS 7-7 .....     | 121/BAS |
| 2-6.....          |   | generic | FS 7-8 .....     | 121/BAS |
| FS 2-7 .....      |   | 121/BAS | FS 7-9 .....     | 121/BAS |
| FS 2-8 .....      |   | 121/BAS | FS 7-10 .....    | 121/BAS |
| FS 2-9 .....      |   | 121/BAS | FS 7-11 .....    | 121/BAS |
| FS 2-10 .....     |   | 121/BAS | FS 7-12 .....    | 121/BAS |
| FS 2-11 .....     |   | 121/BAS | FS 7-13 .....    | 121/BAS |
| FS 2-12 .....     |   | 121/BAS | FS 7-14 .....    | 121/BAS |
| 3-1.....          |   | generic | FS 7-15 .....    | 121/BAS |
| 3-2.....          |   | generic | FS 7-16 .....    | 121/BAS |
| 3-3.....          |   | generic | FS 7-17 .....    | 121/BAS |
| 3-4.....          |   | generic | FS 7-18 .....    | 121/BAS |
| 3-5.....          |   | generic | FS 7-19 .....    | 121/BAS |
| 3-6.....          |   | generic | FS 7-20 .....    | 121/BAS |
| 3-7.....          |   | generic | FS 7-21 .....    | 121/BAS |
| 3-8.....          |   | generic | FS 7-22 .....    | 121/BAS |
| CC 3-9.....       |   | generic | FS 7-23 .....    | 121/BAS |
| CC 3-10.....      |   | generic | FS 7-24 .....    | 121/BAS |

\* – Omit from flight book

|                   |         |                   |         |
|-------------------|---------|-------------------|---------|
| FS 7-25 .....     | 121/BAS | 9-3 .....         | generic |
| FS 7-26 .....     | 121/BAS | 9-4 .....         | generic |
| FS 7-27 .....     | 121/BAS | 9-5 .....         | generic |
| FS 7-28 .....     | 121/BAS | 9-6 .....         | generic |
| FS 7-29 .....     | 121/BAS | TEMP FS 10-1..... | 121/BAS |
| FS 7-30 .....     | 121/BAS | TEMP FS 10-2..... | ALL/BAS |
| FS 7-31 .....     | 121/BAS | 10-3 .....        | generic |
| FS 7-32 .....     | 121/BAS | 10-4 .....        | generic |
| FS 7-33 .....     | 121/BAS | 10-5 .....        | generic |
| FS 7-34 .....     | 121/BAS | 10-6 .....        | generic |
| FS 7-35 .....     | 121/BAS | 10-7 .....        | generic |
| FS 7-36 .....     | 121/BAS | 10-8 .....        | generic |
| FS 7-37 .....     | 121/BAS | 10-9 .....        | generic |
| FS 7-38 .....     | 121/BAS | 10-10 .....       | generic |
| FS 7-39 .....     | 121/BAS | FS CC 10-11.....  | 121/BAS |
| FS 7-40 .....     | 121/BAS | FS CC 10-12.....  | 121/BAS |
| FS 7-41 .....     | 121/BAS | 11-1 .....        | generic |
| FS 7-42 .....     | 121/BAS | 11-2 .....        | generic |
| FS 7-43 .....     | 121/BAS | 11-3 .....        | generic |
| FS 7-44 .....     | 121/BAS | 11-4 .....        | generic |
| FS 7-45 .....     | 121/BAS | 12-i .....        | generic |
| FS 7-46 .....     | 121/BAS | 12-ii.....        | generic |
| FS 7-47 .....     | 121/BAS | TEMP FS 12-1..... | 121/BAS |
| FS 7-48 .....     | 121/BAS | TEMP FS 12-2..... | ALL/BAS |
| FS 7-49 .....     | 121/BAS | 12-3 .....        | generic |
| FS 7-50 .....     | 121/BAS | 12-4 .....        | generic |
| TEMP FS 8-1 ..... | 121/BAS | 12-5 .....        | generic |
| TEMP FS 8-2 ..... | ALL/BAS | 12-6 .....        | generic |
| 8-3.....          | generic | 12-7 .....        | generic |
| 8-4.....          | generic | 12-8 .....        | generic |
| 8-5.....          | generic | 12-9 .....        | generic |
| 8-6.....          | generic | 12-10 .....       | generic |
| FS 8-7 .....      | 121/BAS | 12-11 .....       | generic |
| FS 8-8 .....      | 121/BAS | 12-12 .....       | generic |
| FS 8-9 .....      | 121/BAS | 12-13 .....       | generic |
| FS 8-10 .....     | 121/BAS | 12-14 .....       | generic |
| FS 8-11 .....     | 121/BAS | 12-15 .....       | generic |
| FS 8-12 .....     | 121/BAS | 12-16 .....       | generic |
| FS 8-13 .....     | 121/BAS | 12-17 .....       | generic |
| FS 8-14 .....     | 121/BAS | 12-18 .....       | generic |
| FS 8-15 .....     | 121/BAS | FS 12-19.....     | 121/BAS |
| FS 8-16 .....     | 121/BAS | FS 12-20.....     | 121/BAS |
| FS 8-17 .....     | 121/BAS | 13-1 .....        | generic |
| FS 8-18 .....     | 121/BAS | 13-2 .....        | generic |
| FS 8-19 .....     | 121/BAS | 13-3 .....        | generic |
| FS 8-20 .....     | 121/BAS | 13-4 .....        | generic |
| FS 8-21 .....     | 121/BAS | 14-1 .....        | generic |
| FS 8-22 .....     | 121/BAS | 14-2 .....        | generic |
| FS 8-23 .....     | 121/BAS | 14-3 .....        | generic |
| FS 8-24 .....     | 121/BAS | 14-4 .....        | generic |
| 9-1 .....         | generic | 14-5 .....        | generic |
| 9-2 .....         | generic | 14-6 .....        | generic |

|                    |         |               |         |
|--------------------|---------|---------------|---------|
| 14-7.....          | generic | FS 16-21..... | 121/BAS |
| 14-8.....          | generic | FS 16-22..... | 121/BAS |
| 14-9.....          | generic | FS 16-23..... | 121/BAS |
| 14-10.....         | generic | FS 16-24..... | 121/BAS |
| 14-11.....         | generic | FS 16-25..... | 121/BAS |
| 14-12.....         | generic | FS 16-26..... | 121/BAS |
| 14-13.....         | generic | FS 16-27..... | 121/BAS |
| 14-14.....         | generic | FS 16-28..... | 121/BAS |
| 14-15.....         | generic | FS 16-29..... | 121/BAS |
| 14-16.....         | generic | FS 16-30..... | 121/BAS |
| 14-17.....         | generic | FS 16-31..... | 121/BAS |
| 14-18.....         | generic | FS 16-32..... | 121/BAS |
| 14-19.....         | generic | FS 16-33..... | 121/BAS |
| 14-20.....         | generic | FS 16-34..... | 121/BAS |
| 14-21.....         | generic | FS 16-35..... | 121/BAS |
| 14-22.....         | generic | FS 16-36..... | 121/BAS |
| 15-1.....          | generic | FS 16-37..... | 121/BAS |
| 15-2.....          | generic | FS 16-38..... | 121/BAS |
| 15-3.....          | generic | FS 16-39..... | 121/BAS |
| 15-4.....          | generic | FS 16-40..... | 121/BAS |
| 15-5.....          | generic | FS 16-41..... | 121/BAS |
| 15-6.....          | generic | FS 16-42..... | 121/BAS |
| 15-7.....          | generic | FS 16-43..... | 121/BAS |
| 15-8.....          | generic | FS 16-44..... | 121/BAS |
| 15-9.....          | generic | FS 16-45..... | 121/BAS |
| 15-10.....         | generic | FS 16-46..... | 121/BAS |
| 15-11.....         | generic | FS 17-1.....  | 121/BAS |
| 15-12.....         | generic | FS 17-2.....  | 121/BAS |
| 15-13.....         | generic | FS 17-3.....  | 121/BAS |
| 15-14.....         | generic | FS 17-4.....  | 121/BAS |
| 16-i.....          | generic | FS 17-5.....  | 121/BAS |
| 16-ii .....        | generic | FS 17-6.....  | 121/BAS |
| TEMP FS 16-1 ..... | 121/BAS | FS 17-7.....  | 121/BAS |
| TEMP FS 16-2 ..... | 121/BAS | FS 17-8.....  | 121/BAS |
| FS 16-3 .....      | 121/BAS | FS 17-9.....  | 121/BAS |
| FS 16-4 .....      | 121/BAS | FS 17-10..... | 121/BAS |
| FS 16-5 .....      | 121/BAS | FS 17-11..... | 121/BAS |
| FS 16-6 .....      | 121/BAS | FS 17-12..... | 121/BAS |
| FS 16-7 .....      | 121/BAS | FS 17-13..... | 121/BAS |
| FS 16-8 .....      | 121/BAS | FS 17-14..... | 121/BAS |
| FS 16-9 .....      | 121/BAS | FS 17-15..... | 121/BAS |
| FS 16-10 .....     | 121/BAS | FS 17-16..... | 121/BAS |
| FS 16-11 .....     | 121/BAS | FS 17-17..... | 121/BAS |
| FS 16-12 .....     | 121/BAS | FS 17-18..... | 121/BAS |
| FS 16-13 .....     | 121/BAS | FS 17-19..... | 121/BAS |
| FS 16-14 .....     | 121/BAS | FS 17-20..... | 121/BAS |
| FS 16-15 .....     | 121/BAS | FS 17-21..... | 121/BAS |
| FS 16-16 .....     | 121/BAS | FS 17-22..... | 121/BAS |
| FS 16-17 .....     | 121/BAS | FS 17-23..... | 121/BAS |
| FS 16-18 .....     | 121/BAS | FS 17-24..... | 121/BAS |
| FS 16-19 .....     | 121/BAS | FS 17-25..... | 121/BAS |
| FS 16-20 .....     | 121/BAS | FS 17-26..... | 121/BAS |

|                |         |               |           |
|----------------|---------|---------------|-----------|
| FS 17-27 ..... | 121/BAS | FS 18-23..... | 121/BAS   |
| FS 17-28 ..... | 121/BAS | FS 18-24..... | 121/BAS   |
| FS 17-29 ..... | 121/BAS | FS 18-25..... | 121/BAS   |
| FS 17-30 ..... | 121/BAS | FS 18-26..... | 121/BAS   |
| FS 17-31 ..... | 121/BAS | FS 18-27..... | 121/BAS   |
| FS 17-32 ..... | 121/BAS | FS 18-28..... | 121/BAS   |
| FS 18-1 .....  | 121/BAS | FS 18-29..... | 121/BAS   |
| FS 18-2 .....  | 121/BAS | FS 18-30..... | 121/BAS   |
| FS 18-3 .....  | 121/BAS | FS 18-31..... | 121/BAS   |
| FS 18-4 .....  | 121/BAS | FS 18-32..... | 121/BAS   |
| FS 18-5 .....  | 121/BAS | FS 18-33..... | 121/BAS   |
| FS 18-6 .....  | 121/BAS | FS 18-34..... | 121/BAS   |
| FS 18-7 .....  | 121/BAS | 19-i .....    | generic   |
| FS 18-8 .....  | 121/BAS | 19-ii.....    | generic   |
| FS 18-9 .....  | 121/BAS | 19-1 .....    | generic   |
| FS 18-10 ..... | 121/BAS | 19-2 .....    | generic   |
| FS 18-11 ..... | 121/BAS | 19-3 .....    | generic   |
| FS 18-12 ..... | 121/BAS | 19-4 .....    | generic   |
| FS 18-13 ..... | 121/BAS | 19-5 .....    | generic   |
| FS 18-14 ..... | 121/BAS | 19-6 .....    | generic   |
| FS 18-15 ..... | 121/BAS | 19-7 .....    | generic   |
| FS 18-16 ..... | 121/BAS | 19-8 .....    | generic   |
| FS 18-17 ..... | 121/BAS | 19-9 .....    | generic   |
| FS 18-18 ..... | 121/BAS | 19-10 .....   | generic   |
| FS 18-19 ..... | 121/BAS | 20-1 .....    | * generic |
| FS 18-20 ..... | 121/BAS | 20-2 .....    | * generic |
| FS 18-21 ..... | 121/BAS |               |           |
| FS 18-22 ..... | 121/BAS |               |           |

#### EVA CUE CARDS

| <u>Title</u>   | <u>Ref. Page</u> | <u>Card No.</u> |
|--|------------------|-----------------|
| SAFER CHECKOUT RESULTS (Front).....                                    | CC 3-9           | generic         |
| SAFER STATUS TROUBLESHOOTING (Back of<br>SAFER CHECKOUT RESULTS) ..... | CC 3-10          | generic         |
| EVA PREBREATHE CUE CARD  |                  |                 |
| (Front) .....  | FS CC 4-11       | EVA-5a/121/O/A  |
| (Back).....  | FS CC 4-12       | EVA-5b/121/O/A  |
| DEPRESS/REPRESS  |                  |                 |
| (Nominal Configuration) (Front) .....                                  | CC A6-2          | generic         |
| FAILED LEAK CHECK  |                  |                 |
| (Back of DEPRESS/REPRESS) .....  | CC 6-4           | generic         |
| EMU/AIRLOCK CONSUMABLES TRACKING                                       |                  |                 |
| CUE CARD   |                  |                 |
| (Front) .....  | FS CC 10-11      | EVA-6a/121/O/A  |
| (Back).....  | FS CC 10-12      | EVA-6b/121/O/A  |

\* – Omit from flight book

|   | <u>CONTENTS</u> | <u>PAGE</u> |
|---|-----------------|-------------|
| 10.2 PSI CABIN .....                      |                 | 1-1         |
| MASK PREBREATHE INITIATE .....            |                 | 1-2         |
| PREP FOR 10.2 PSI CABIN .....             |                 | 1-3         |
| CABIN DEPRESS TO 10.2 PSI.....            |                 | 1-4         |
| 10.2 PSIA DEPRESS CHART.....              |                 | 1-5         |
| 10.2 PSI CABIN CONFIG.....                |                 | 1-6         |
| MASK PREBREATHE TERMINATE .....           |                 | 1-6         |
| 10.2 PSI MAINTENANCE.....                 |                 | 1-7         |
| CABIN REPRESS TO 14.7 PSI.....            |                 | 1-8         |
| 14.7 PSI CABIN CONFIG.....                |                 | 1-9         |
| AIRLOCK CONFIG .....                      | TEMP FS         | 2-1         |
| AIRLOCK PREP .....                        | TEMP FS         | 2-2         |
| EMU SWAP .....                            |                 | 2-3         |
| BOOSTER FAN DEACTIVATION/REMOVAL.....     |                 | 2-4         |
| BOOSTER FAN INSTALLATION/ACTIVATION.....  |                 | 2-4         |
| EVA TOOL TRANSFER .....                   |                 | 2-4         |
| EMU REMOVAL .....                         |                 | 2-4         |
| EMU INSTALLATION .....                    |                 | 2-4         |
| EMU CHECKOUT PREP .....                   |                 | 2-5         |
| LTA RESTRAINT STRAP REMOVAL .....         |                 | 2-6         |
| LTA RESTRAINT STRAP INSTALLATION .....    |                 | 2-6         |
| EMU PREP FOR ISS TRANSFER .....           |                 | FS 2-7      |
| PRE EVA 1 EMU TRANSFER AND RECONFIG ..... |                 | FS 2-8      |
| POST EVA 2 EMU RECONFIG AND TRANSFER..... |                 | FS 2-9      |
| CHECKOUTS.....                            |                 | 3-1         |
| EMU CHECKOUT .....                        |                 | 3-2         |
| EMU POWERUP .....                         |                 | 3-2         |
| COMM CHECK.....                           |                 | 3-2         |
| PRIMARY REGULATOR/FAN/PUMP CHECK.....     |                 | 3-3         |
| SOP CHECK.....                            |                 | 3-5         |
| BATTERY CHARGE CHECK INIT .....           |                 | 3-5         |
| BATTERY CHARGE CHECK TERM .....           |                 | 3-6         |
| EMU SWAP DURING CHECKOUT .....            |                 | 3-6         |
| POST EMU C/O RECONFIG.....                |                 | 3-7         |
| SAFER CHECKOUT .....                      |                 | 3-7         |
| SELF TEST SEQUENCE .....                  |                 | 3-8         |
| SAFER CHECKOUT RESULTS.....               |                 | CC 3-9      |
| SAFER STATUS TROUBLESHOOTING .....        |                 | CC 3-10     |
| REBA POWERED HARDWARE CHECKOUT .....      |                 | 3-11        |
| EVA PREP .....                            | TEMP FS         | 4-1         |
| MIDDECK PREP .....                        | TEMP FS         | 4-2         |
| EVA PREP.....                             | TEMP FS         | 4-2         |
| PREP FOR DONNING .....                    |                 | TEMP FS 4-2 |
| EMU DONNING .....                         |                 | 4-4         |
| EMU CHECK .....                           |                 | 4-5         |
| EMU PURGE .....                           |                 | 4-6         |
| EMU PREBREATHE .....                      |                 | 4-6         |
| SAFER DONNING .....                       |                 | 4-6         |
| EVA COMM CONFIG .....                     |                 | 4-8         |
| EVA COMM DECONFIG .....                   |                 | 4-8         |
| CO2 RMVL SYS DEACT .....                  |                 | 4-9         |
| CO2 RMVL SYS ACT .....                    |                 | 4-9         |
| EVA PREBREATHE CUE CARD .....             |                 | FS CC 4-11  |

|  |             |
|--|-------------|
| EMU STATUS .....                             | 5-1         |
| EMU STATUS .....                             | 5-2         |
| DEPRESS/REPRESS .....                        | A6-1        |
| DEPRESS/REPRESS (NOM A/L) .....              | CC A6-2     |
| FAILED LEAK CHECK .....                      | 6-3         |
| FAILED LEAK CHECK (5 PSI) .....              | CC 6-4      |
| FAILED LEAK CHECK (14.7/10.2 PSI) .....      | CC 6-4      |
| TIMELINES .....                              | FS 7-1      |
| EVA 1 .....                                  | FS 7-3      |
| EVA 1 BRIEFING CARD .....                    | FS 7-4      |
| EVA 1 TOOL CONFIG .....                      | FS 7-5      |
| EVA 1 INHIBIT PAD .....                      | FS 7-6      |
| EVA 1 NOTES, CAUTIONS, & WARNINGS .....      | FS 7-7      |
| EVA 1 SUMMARY TIMELINE .....                 | FS 7-8      |
| EVA 1 EGRESS .....                           | FS 7-9      |
| SETUP .....                                  | FS 7-10     |
| LOAD EVALUATIONS .....                       | FS 7-13     |
| CLEANUP .....                                | FS 7-18     |
| EVA 1 INGRESS .....                          | FS 7-20     |
| EVA 2 .....                                  | FS 7-21     |
| EVA 2 BRIEFING CARD .....                    | FS 7-22     |
| EVA 2 TOOL CONFIG .....                      | FS 7-23     |
| EVA 2 INHIBIT PAD .....                      | FS 7-24     |
| EVA 2 NOTES, CAUTIONS, & WARNINGS .....      | FS 7-25     |
| EVA 2 SUMMARY TIMELINE .....                 | FS 7-26     |
| EVA 2 EGRESS .....                           | FS 7-27     |
| FRGF REMOVAL .....                           | FS 7-28     |
| FGB TO PM INSTALLATION .....                 | FS 7-30     |
| PUMP MODULE RETRIEVE .....                   | FS 7-33     |
| FGB S1 ATA INSTALLATION .....                | FS 7-35     |
| PUMP MODULE INSTALLATION .....               | FS 7-37     |
| SHOSS-ED RETRIEVAL .....                     | FS 7-39     |
| CP9 ETCG INSTALLATION .....                  | FS 7-42     |
| SHOSS-ED INSTALLATION .....                  | FS 7-48     |
| EVA 2 INGRESS .....                          | FS 7-50     |
| TOOLS AND STOWAGE .....                      | TEMP FS 8-1 |
| PSA STOWAGE .....                            | TEMP FS 8-2 |
| PGT CHECKOUT .....                           | 8-3         |
| 760XD PGSC-PGT CONNECTION .....              | 8-4         |
| PROGRAM PGT SETTINGS .....                   | 8-4         |
| DOWNLOAD/ERASE EVENT LOG .....               | 8-5         |
| PGT CONTINGENCIES .....                      | 8-6         |
| PORT LIGHTWEIGHT TOOL STOWAGE ASSEMBLY ..... | FS 8-7      |
| STBD LIGHTWEIGHT TOOL STOWAGE ASSEMBLY (TBD) |             |
| PISTOL GRIP TOOL .....                       | FS 8-8      |
| PGT SETTINGS TABLE .....                     | FS 8-9      |
| PGT/FASTENER REF DATA .....                  | FS 8-10     |
| EVA TOOLS STOWAGE (TBD)                      |             |
| ISS EVA TOOLS BY ITEM (TBD)                  |             |
| ISS EVA TOOLS BY LOCATION (TBD)              |             |
| TOOLBOX STOWAGE .....                        | FS 8-11     |
| TOOLBOX PANEL AND SLOT LOCATIONS .....       | FS 8-12     |
| SHUTTLE EMU EQUIPMENT BY ITEM .....          | FS 8-13     |
| SHUTTLE EMU EQUIPMENT BY LOCATION .....      | FS 8-15     |

|   |              |
|---|--------------|
| SHUTTLE EVA TOOLS BY ITEM .....                       | FS 8-17      |
| SHUTTLE EVA TOOLS BY LOCATION.....                    | FS 8-20      |
| APFR MANAGEMENT .....                                 | FS 8-23      |
| <br>POST EVA .....                                    | 9-1          |
| POST EVA.....   | 9-2          |
| SUIT DOFFING .....                                    | 9-2          |
| SAFER DOFFING.....                                    | 9-2          |
| EMU WATER RECHARGE .....                              | 9-3          |
| SAFER STOW .....                                      | 9-4          |
| SUIT DRYING/SEAL WIPE .....                           | 9-4          |
| OXYGEN RECHARGE VERIFICATION.....                     | 9-4          |
| WATER FILL VERIFICATION .....                         | 9-4          |
| EMU POWERDOWN .....                                   | 9-5          |
| <br>EMU MAINT/RECHARGE.....                           | TEMP FS 10-1 |
| WATER RECHARGE .....                                  | TEMP FS 10-2 |
| EMU POWERUP .....                                     | TEMP FS 10-2 |
| WATER FILL.....                                       | TEMP FS 10-2 |
| OXYGEN RECHARGE VERIFICATION.....                     | 10-3         |
| WATER FILL VERIFICATION .....                         | 10-3         |
| EMU LiOH CHANGEOUT .....                              | 10-4         |
| MIDDECK EMU BATTERY RECHARGE/LiOH REPLACEMENT.....    | 10-5         |
| INITIATE .....  | 10-5         |
| TERMINATE .....                                       | 10-5         |
| IN-SUIT EMU BATTERY RECHARGE/CHARGE VERIFICATION..... | 10-6         |
| INITIATE .....  | 10-6         |
| TERMINATE .....                                       | 10-6         |
| EMU POWERDOWN.....                                    | 10-6         |
| HELMET LIGHT/PGT BATTERY RECHARGE .....               | 10-7         |
| INITIATE .....  | 10-7         |
| TERMINATE .....                                       | 10-7         |
| REBA BATTERY INSTALLATION.....                        | 10-8         |
| EMU BATTERY REMOVAL/INSTALL.....                      | 10-8         |
| HELMET LIGHT BULB CHANGEOUT .....                     | 10-9         |
| REBA BATTERY RECHARGE.....                            | 10-10        |
| INITIATE .....  | 10-10        |
| TERMINATE .....                                       | 10-10        |
| EMU/AIRLOCK CONSUMABLES TRACKING CUE CARD .....       | FS CC 10-11  |
| <br>POST EVA ENTRY PREP .....                         | 11-1         |
| POST EVA ENTRY PREP.....                              | 11-2         |
| SAFER ENTRY STOW.....                                 | 11-2         |
| POST ISS EVA ENTRY PREP.....                          | 11-3         |
| SAFER ENTRY STOW.....                                 | 11-3         |
| <br><u>OFF-NOMINAL PROCEDURES.....</u>                | 12-i         |
| EMU CONTINGENCY PROCS.....                            | TEMP FS 12-1 |
| DISPLAY LOSS DURING POWER TRANSFER                    |              |
| (WARM RESTART) .....                                  | TEMP FS 12-2 |
| VACUUM H2O RECHARGE (MANNED) .....                    | TEMP FS 12-2 |
| LiOH REPLACEMENT (MANNED) .....                       | 12-3         |
| BATTERY REPLACEMENT (MANNED).....                     | 12-4         |
| WATER DUMP .....                                      | 12-5         |
| SCU SWAP (UNMANNED) .....                             | 12-6         |
| SCU SWAP (MANNED) .....                               | 12-6         |

|   |          |
|---|----------|
| EMU COLD RESTART (MANNED).....  | 12-6     |
| 12.1 CHEMICAL CHECK/DECONTAMINATION .....                               | 12-7     |
| CONTAMINATION TEST .....  | 12-10    |
| SAFER BATTERY CHANGEOUT .....   | 12-11    |
| BENDS TREATMENT ADAPTER (BTA) INSTALLATION (IN-SUIT) .....              | 12-12    |
| BTA PREP .....  | 12-12    |
| BTA TREATMENT .....   | 12-12    |
| BENDS TREATMENT ADAPTER (BTA) INSTALLATION<br>(POST SUIT DOFFING) ..... | 12-14    |
| BTA PREP .....  | 12-14    |
| BTA TREATMENT .....   | 12-14    |
| EMU RESIZE.....   | 12-17    |
| STS-121 NOMINAL EMU SIZING MATRIX .....                                 | FS 12-19 |
| EMU CONTINGENCY RESIZE MATRIX .....                                     | FS 12-20 |
| <br>DAP/EVA RESCUE/RETRIEVE .....                                       | 13-1     |
| EVA ORBITER CONFIGURATION .....   | 13-2     |
| EVA RESCUE/RETRIEVE .....   | 13-4     |
| <br>ORBITER CONTINGENCY EVA .....                                       | 14-1     |
| PAYLOAD BAY EVA NOMENCLATURE .....                                      | 14-2     |
| RMS/PRLA CONTINGENCY EVA .....  | 14-3     |
| 96 BOLT PRE-EVA TOOL CONFIG .....                                       | 14-13    |
| 96 BOLT EVA TIMELINE .....  | 14-14    |
| CAPTURE LATCH MANUAL RELEASE (ODS/PMA).....                             | 14-19    |
| 96 BOLT EVA LAYOUT .....  | 14-21    |
| <br>EVA CUFF CHECKLIST (CIL) .....                                      | 15-1     |
| NORMAL EVA STATUS .....   | 15-2     |
| EVA COMM FREQUENCIES.....   | 15-2     |
| EMU MAL INDEX .....   | 15-2     |
| DECOMPRESSION SICKNESS (DCS) .....                                      | 15-3     |
| ABORT EVA.....  | 15-3     |
| TERMINATE EVA .....   | 15-3     |
| SOP O2 ON .....   | 15-4     |
| BATT AMPS HIGH.....   | 15-4     |
| BATT VDC LOW .....  | 15-4     |
| SUIT P LOW .....  | 15-4     |
| SUIT P HIGH.....  | 15-5     |
| SOP P LOW .....   | 15-5     |
| O2 USE HIGH .....   | 15-5     |
| SUBLM PRESS.....  | 15-5     |
| H2O GP LOW .....  | 15-6     |
| RESRV H2O ON .....  | 15-6     |
| NO VENT FLOW .....  | 15-6     |
| CO2.....  | 15-6     |
| COMM FAILURE.....   | 15-7     |
| MISC MSGS.....  | 15-7     |
| AIR FLOW CONTAMINATION.....   | 15-7     |
| RADIATOR ACTUATOR DISCONNECT .....                                      | 15-8     |
| PLBD DRIVE CUT .....  | 15-8     |
| DOOR DRIVE RESTRAINT .....  | 15-8     |
| DOOR DRIVE DISCONNECT.....  | 15-9     |
| WINCH OPERATIONS .....  | 15-9     |
| 3-PT TOOL INSTALLATION .....  | 15-9     |
| CL LATCH TOOL .....   | 15-10    |

|  |              |
|--|--------------|
| TOOL RESET .....   | 15-10        |
| AIRLOCK LATCH DISCONNECT .....                           | 15-10        |
| HINGE DISCONNECT .....                                   | 15-10        |
| RMS JOINT ALIGN .....                                    | 15-10        |
| RMS SHOULDER BRACE RELEASE .....                         | 15-10        |
| MPM STOW/DEPLOY .....                                    | 15-10        |
| RMS TIEDOWN .....  | 15-11        |
| RMS FLIGHT RELEASABLE GRAPPLE FIXTURE RELEASE .....      | 15-11        |
| PRLA OPEN/CLOSE .....                                    | 15-11        |
| KU ANTENNA STOW .....                                    | 15-12        |
| AIRLOCK EGRESS .....                                     | 15-12        |
| AIRLOCK INGRESS .....                                    | 15-12        |
| <br><u>FLIGHT SPECIFIC REFERENCE</u> .....               | 16-i         |
| UNSCHEDEDLED/CONTINGENCY EVA TASKS .....                 | TEMP FS 16-1 |
| STS-121 WORKAROUNDS CRIBSHEET .....                      | TEMP FS 16-2 |
| ORU CONTINGENCY TRANSFER .....                           | FS 16-5      |
| RELEASE ROEU LATCHES .....                               | FS 16-8      |
| LATCH ROEU LATCHES .....                                 | FS 16-9      |
| STOW ROEU ARM .....                                      | FS 16-10     |
| MATE ROEU ARM .....                                      | FS 16-11     |
| ROEU OVERVIEW .....                                      | FS 16-12     |
| CLEAR/RESTRAIN CBM CAPTURE LATCH .....                   | FS 16-13     |
| MANUALLY OPEN/CLOSE CBM PETAL .....                      | FS 16-16     |
| REMOVE/REPLACE CENTER DISK COVER .....                   | FS 16-21     |
| REMOVE/REPLACE CBM CAPTURE LATCH .....                   | FS 16-26     |
| REMOVE/REPLACE CBM CONTROLLER PANEL ASSEMBLY (CPA) ..... | FS 16-31     |
| REMOVE/REPLACE CBM PETAL .....                           | FS 16-37     |
| CONTINGENCY EVA INHIBIT PAD .....                        | FS 16-43     |
| CONTINGENCY NOTES, CAUTIONS, AND WARNINGS .....          | FS 16-45     |
| <br>GENERIC EVA REFERENCE .....                          | FS 17-1      |
| P1 OVERVIEW .....  | FS 17-3      |
| P1 FORWARD FACE (FACE 1) .....                           | FS 17-4      |
| P1 AFT FACE (FACE 4) .....                               | FS 17-5      |
| P1 ZENITH SIDE (FACE 2) .....                            | FS 17-6      |
| P1 NADIR SIDE (FACE 6) .....                             | FS 17-7      |
| P1 HANDRAILS AND WIFs, FACES 1, 2, AND 6 .....           | FS 17-8      |
| P1 HANDRAILS AND WIFs, FACE 4 .....                      | FS 17-9      |
| P1 ORUs .....  | FS 17-12     |
| QD TOOLBAGS INSTALLED ON CREWLOCK ZENITH .....           | FS 17-14     |
| QD TOOLBAG CONTENTS .....                                | FS 17-15     |
| FLUID QD BAIL LEVERS .....                               | FS 17-16     |
| FLUID QD RELEASE TOOLS .....                             | FS 17-17     |
| FLUID QD CAP TOOLS .....                                 | FS 17-18     |
| 1.0-IN BUTTON DEPRESS TOOL .....                         | FS 17-19     |
| 1.0-IN BUTTON DEPRESS TOOL – INSTALLED .....             | FS 17-20     |
| 1.5-IN FLUID QD SPOOL POSITIONING DEVICE .....           | FS 17-21     |
| 1.0-IN FLUID QD SPOOL POSITIONING DEVICE .....           | FS 17-22     |
| 0.5-IN FLUID QD SPOOL POSITIONING DEVICE .....           | FS 17-23     |
| 0.5-IN SPD BOOTIE EXTENSION .....                        | FS 17-23     |
| TETHER SHUTTLE STOWAGE .....                             | FS 17-24     |
| MT STOP .....  | FS 17-25     |
| WVS EXTERNAL TRANSCEIVER ASSY (WETA) .....               | FS 17-26     |
| NODE WETA INSTALL – CP12 .....                           | FS 17-27     |
| P1 WETA INSTALL – CP08 .....                             | FS 17-28     |
| TRRJ OVERVIEW – STBD .....                               | FS 17-29     |

|   |          |
|---|----------|
| TRRJ OVERVIEW – P1 PORT/S1 STBD.....                | FS 17-30 |
| RADIATOR OVERVIEW.....                              | FS 17-31 |
| UHF ANTENNA .....                                   | FS 17-32 |
| <br>FLIGHT SPECIFIC EVA REFERENCE .....             | FS 18-1  |
| STS-121 PAYLOAD BAY LAYOUT.....                     | FS 18-3  |
| ESP2 HR AND WIF LAYOUT (ZENITH).....                | FS 18-4  |
| ESP2 HR AND WIF LAYOUT (NADIR).....                 | FS 18-5  |
| ESP2 FINAL CONFIG .....                             | FS 18-6  |
| ICC LAUNCH CONFIG (TOP AND BOTTOM VIEWS) .....      | FS 18-7  |
| ICC LANDING CONFIG .....                            | FS 18-8  |
| ICC LAYOUT .....                                    | FS 18-9  |
| SHOSS-ED WITH AGB .....                             | FS 18-10 |
| DDCU COLDPLATE (INSIDE SHOSS-ED BOX) .....          | FS 18-11 |
| MBSU COLDPLATE (INSIDE SHOSS-ED BOX) .....          | FS 18-12 |
| ADJUSTABLE GRAPPLE BAR .....                        | FS 18-13 |
| ADJUSTABLE GRAPPLE BAR PINS.....                    | FS 18-14 |
| FGB MOUNTING PLATE .....                            | FS 18-15 |
| FGB INSTALL LOCATION ON PUMP MODULE .....           | FS 18-16 |
| FGB INSTALLED ON PUMP MODULE .....                  | FS 18-17 |
| PLASTIC FGB BASE SIMULATOR.....                     | FS 18-18 |
| FRAM STRUCTURAL COMPONENT OVERVIEW .....            | FS 18-19 |
| FLIGHT RELEASABLE ATTACHMENT MECHANISM (FRAM) ..... | FS 18-20 |
| FRAM ACTIVE AND PASSIVE INTERFACES.....             | FS 18-21 |
| ACTIVE FRAM .....                                   | FS 18-22 |
| VSSA STANCHIONS ON ESP2.....                        | FS 18-23 |
| CAMERA INSTALL CP9.....                             | FS 18-24 |
| VIDEO STANCHION .....                               | FS 18-25 |
| VSSA DUMMY BOX.....                                 | FS 18-26 |
| ETVCG COMPONENTS .....                              | FS 18-27 |
| ETVCG PAN AND TILT RELEASE LEVERS .....             | FS 18-28 |
| LMC LAYOUT.....                                     | FS 18-29 |
| DTO 848 TPS REPAIR SAMPLE BOX .....                 | FS 18-30 |
| DTO 848 SAMPLE BOX ACCESS HATCH.....                | FS 18-31 |
| DTO 848 SAMPLE BOX COMPONENTS .....                 | FS 18-32 |
| DTO 849 WS STABILIZATION LOAD CELL CONCEPT .....    | FS 18-34 |
| <br><u>EVA EMERGENCY</u> .....                      | 19-i     |
| EMERGENCY PROCEDURES.....                           | 19-1     |
| EMERGENCY AIRLOCK REPRESS .....                     | 19-3     |
| EMERGENCY AIRLOCK REPRESS.....                      | 19-4     |
| POST EMERGENCY AIRLOCK REPRESS.....                 | 19-4     |
| SAFER RESCUE.....                                   | 19-5     |
| SAFER RESCUE .....                                  | 19-6     |
| 19.1 DCS TREATMENT .....                            | 19-7     |
| <br>CUE CARD CONFIGURATION .....                    | 20-1     |